

RADIATION SURVEY WORKSHEET

eXaminer Radiation Survey Information

Airport: <i>Palm Beach International Airport</i>		Scanner Location: <i>Baggage Handling Room</i>		Case#: <i>PBI-C299039</i>	
Personnel Performing Radiation Survey:				Date Survey Performed: <i>4/28/2010</i>	
Scanner Serial Number: <i>6325</i>		Entrance Tunnel Serial Number: <i>2262A</i>		Exit Tunnel Serial Number: <i>2262B</i>	
High Reading: <i>27</i>	Average Reading: <i>14.28</i>	Min. Reading: <i>6</i>	High Reading: <i>97</i>	Average Reading: <i>23.65</i>	Min. Reading: <i>9</i>
Good		Good		Good	
Radiation Meter:	Type Meter: <i>451P</i>	Meter Serial Number: <i>263</i>	Calibration Due Date: <i>October 22, 2010</i>		
NO TESTS					

Complete Radiation Survey (CRS)		Record Voltage and Bean Current here:					
Rename this Document before starting the Survey to: PBI-CRS-28DEC2010-6325		Voltage:		<i>164</i>	KV	Beam Current:	<i>9.8</i> mA
		Maximum Safe Readings		Scanner	<i>350</i>	Tunnels	<i>350</i>
Step:	Procedure	Expected results					
1.	Set Up: Obtain Invision Ion Chamber Survey Meter and in an area away from the scanners, turn on the meter by pressing the On-Off key. Wait approx. 4 minutes for the meter to run through the initialization procedure.	The GUI will be visible and will indicate Standby. After the radiation meter initialization procedure is complete the meter will be reading less than 20 µR/hr and the meter will be ready for use.					
2.	The scanner will be in Standby. Change the conveyor switch on the scanner to Stop. Change the exit tunnel conveyor switch to Off to stop the conveyor.	Both conveyors should be stopped.					
3.	On the GUI dropdown screen, select diagnostic, followed by Radiation Survey. A radiation survey window will appear. Click "Turn On" button to turn x-rays on. Turn on x-rays prompt will say "Place survey bag on belt". Place IQTK bag on Entry Conveyor Belt.	A window indicating "Radiation Survey" will appear.					
4.	When "Bag in survey position" appears, go to the FCC monitor and select "2" then <Enter>, verify and record the voltage and current in the displayed on the FCC screen in the planks provided above.	The high voltage is between 144KV and 176KV. The current is between 8.8mA and 10.6mA and the scanner X-ray indicator lights are on.					
5.	Survey one of the areas indicated by the boxes in Appendix A2. Record the highest reading within the area. Repeat the process until all areas are surveyed and readings are recorded.	As the survey is conducted, the radiation meter indicates the degree of radiation emission.					
6.	Review all radiation data sheets for high readings.	Readings shall not exceed 350 uR/hr in any box.					
7.	After radiation survey is complete, click on "Start Conveyor" button on the GUI. Click the "Turn Off" button to turn off x-rays. Next click "Done". The IQTK bag will eject from exit tunnel. EDAC will reboot.	IQTK bag is ejected and scanner reboots.					
7.	Visually inspect the entrance and exit of the system for X-ray caution hazard signs.	X-ray hazard signs reading "Do not insert any part of the body when system is energized" are posted at entrance and exit of system.					
9.	Fill out the eXaminer radiation sticker and adhere to to the frame of the eXaminer under door #5 on the left side of the scanner.	Readings shall not exceed 350 uR/hr in any box.					

RADIATION SURVEY WORKSHEET


1		4		7	
16		17		10	
2		5		8	
17		27		18	
3		6		9	
14		19		16	
Exit Tunnel		Scanner		Entrance Tunnel	

Top View		
Scattered Radiation Measurement Points Worksheet		
Record highest reading per panel		
1	Exit Conveyor Top Panel	16
2	Exit Conveyor Top Panel	17
3	Exit Conveyor Top Panel	14
4	Scanner Conveyor Top Panel	17
5	Scanner Conveyor Top Panel	27
6	Scanner Conveyor Top Panel	19
7	Entrance Conveyor Top Panel	10
8	Entrance Conveyor Top Panel	18
9	Entrance Conveyor Top Panel	16

GOOD

Highest Reading	27
Average Reading	17
Lowest Reading	10

RADIATION SURVEY WORKSHEET



SYSTEM - SIDE PROFILE VIEW (Opposite AC Side)

Scattered Radiation Measurement Points Worksheet		
Record highest reading per panel		μR/Hr
1	Entrance Conveyor Panel	9
2	Entrance Conveyor Panel	12
3	Entrance Conveyor Panel	24
4	Entrance Conveyor Panel	16
5	Entrance Conveyor / Scanner Panel	17
6	Upper Scanner Panel	6
7	Middle Scanner Panel	8
8	Lower Scanner Panel	12
9	Upper Scanner Panel	10
10	Middle Scanner Panel	14
11	Lower Scanner Panel	17
12	Exit Conveyor / Scanner Panel	14
13	Exit Conveyor Panel	22
14	Exit Conveyor Panel	48
15	Exit Conveyor Panel	16
16	Exit Conveyor Panel	12


No PROBLEM

Highest Reading 48

Average Reading 16

Low Reading 6

RADIATION SURVEY WORKSHEET





SYSTEM - SIDE PROFILE VIEW (AC Side)		
Scattered Radiation Measurement Points Worksheet		
Record highest reading per panel	µR/Hr	No PROBLEM
1 Exit Conveyor Panel	11	
2 Exit Conveyor Panel	12	
3 Exit Conveyor Panel	43	
4 Exit Conveyor Panel	18	
5 Exit Conveyor / Scanner Panel	16	
6 Upper Scanner Pane	15	
7 Middle Scanner Panel	12	
8 Lower Scanner Panel	16	
9 Upper Scanner Panel	9	
10 Middle Scanner Panel	11	
11 Lower Scanner Panel	17	
12 Entrance Conveyor / Scanner Panel	9	
13 Entrance Conveyor Panel	15	
14 Entrance Conveyor Panel	10	

GOOD

Highest Reading	43
Average Reading	15
Low Reading	9

RADIATION SURVEY WORKSHEET

SYSTEM - FACES (End Views)



eXaminer entrance

eXaminer exit

SYSTEM - FACES (End Views)		
Scattered Radiation Measurement Points Worksheet		No PROBLEM
Record highest reading per panel		µR/Hr
1	Scanner Panel	8
2	Scanner Top Panel	18
3	Scanner Panel	10
4	Belt Entrance	97
5	Entrance Lower Panel	13
6	Belt Lower Facia Cover Entrance	56
7	Scanner Panel	12
8	Scanner Top Panel	8
9	Scanner Panel	9
10	Belt Exit	94
11	Exit Lower Panel	8
12	Belt Lower Facia Cover Exit	40

GOOD

Highest Reading	97
Average Reading	31
Low Reading	8